

55 Walker Drive, Brampton, Ontario, L6T 5K5
Phone: (905) 456-2603
Fax: (905) 456-1383

TROUBLE SHOOTING

Manual Pump Fails To Raise ERGONOMIC 3000

1. To raise the ERGONOMIC 3000 manually pump the handle. Your ERGONOMIC 3000 has an automatic neutral sensor which activates the pump cylinder when **brisk** pumping action is detected. A gentle pull/pump on the handle will engage the neutral position and the handle can be moved without lifting of the forks. This will enable you to move the ERGONOMIC 3000 from one place to another without activating the pump.
2. There may be an air lock in the hydraulic system. Pull-up and hold control lever and simultaneously pump the handle several times (8-10). Operate pump normally to raise ERGONOMIC 3000.

FOR THESE AND ALL OTHER TROUBLE SHOOTING QUESTIONS PLEASE CONTACT YOUR LOCAL AUTHORIZED LIFT-RITE DEALER.